

We Make Security Better

WEBICS PALM



Before using the product, be sure to read this user manual and 'Safety Precautions' and use it correctly.

Keep this manual in a place where anyone who uses the product can see it at any time. The product warranty is included in this manual.

* The appearance and specifications of the product are subject to change without prior notice to improve product functions.



Table of Contents

1.111	stallation Precautions	01
1-1	Installation Precautions	01
1-1	Safety Precautions	01
2 Dr	aduct Components	02
2. FI	oduct components	UZ
2-1	Components	02
2-2	Sold separately (optional)	02
2-3	Safety Precautions	03
3. Na	mes & Functions of each part	04
3-1	Product Front	04
3-2	Product Rear	04
4. Pr	oduct Size	05
4. Pr 5. In	oduct Size stallation Environment	05 06
4. Pr 5. In 5-1	oduct Size stallation Environment Installation Location	05 06 06
4. Pr 5. In 5-1 5-2	oduct Size stallation Environment Installation Location Cautions in use	05 06 06 06
4. Pr 5. In 5-1 5-2 6. Pr	oduct Size stallation Environment Installation Location Cautions in use oduct Installation	05 06 06 06
4. Pr 5. In 5-1 5-2 6. Pr	oduct Size stallation Environment Installation Location Cautions in use oduct Installation	05 06 06 06 06
4. Pr 5. In 5-1 5-2 6. Pr 6-1 6-2	oduct Size stallation Environment Installation Location Cautions in use oduct Installation Bracket Installation	05 06 06 06 07 07
4. Pr 5. In 5-1 5-2 6. Pr 6-1 6-2 6-3	oduct Size stallation Environment Installation Location Cautions in use oduct Installation Bracket Installation Power Connection RI45 Connection	05 06 06 07 07 07
4. Pr 5. In 5-1 5-2 6. Pr 6-1 6-2 6-3 6-4	oduct Size stallation Environment Installation Location Cautions in use oduct Installation Bracket Installation Power Connection RJ45 Connection Relay terminal Connection	05 06 06 07 07 07 07
4. Pr 5. In 5-1 5-2 6. Pr 6-1 6-2 6-3 6-4 6-5	oduct Size stallation Environment Installation Location Cautions in use oduct Installation Bracket Installation Power Connection RJ45 Connection Relay terminal Connection Fixing a product w/ bracket	05 06 06 07 07 07 07 08 08
4. Pr 5. In 5-1 5-2 6. Pr 6-1 6-2 6-3 6-4 6-5 6-6	oduct Size stallation Environment Installation Location Cautions in use oduct Installation Bracket Installation Power Connection RJ45 Connection Relay terminal Connection Fixing a product w/ bracket Fixing the product	05 06 06 07 07 07 07 08 08 09 09

7. Managing Program	10
1-1 Program Download	10
8. Device Registration	11
9. User Registration	14
9-1 Vein Registration	14
9-2 Card Registration	17
10. Managing Access Rights	21
11. Product Use	23
11-1 Recognizing veins	23
11-2 Recognizing a card	23
12. LED indication Cases	24
12-1 Status In Use	24
12-2 Registration Status	24
13. Product Specifications	25

1. Precautions

1-1 Installation Precautions

- 1. Consult a professional for installation and repair of the product. If necessary, please contact our customer support team
- 2. Do not install or use the product in dusty or easily contaminated places. Dust or foreign substances may cause product failure or malfunction.
- 3. Do not install or use the product near devices that generate heat or moisture, such as air conditioners, heating appliances, and humidifiers, or where direct sunlight enters.
- 4. This product does not support the waterproof function. Be careful not to expose the product to moisture or get it wet.
- 5. Use this product for indoor use only.
- 6. Be sure to read the instruction manual to use the product correctly.

1-2 Safety Precautions

- 1. If the product makes an unfamiliar sound, smell or smoke, stop using it immediately and contact our customer support team.
- 2. Do not wipe the product with a wet towel or damp cloth. If moisture seeps into the product, it may cause fire, electric shock or malfunction. Wipe it with a soft, dry cloth.
- 3. Do not block the ventilation openings of the product. It may cause fire or malfunction.
- 4. Do not modify or disassemble the product. It may cause fire or malfunction.
- 5. Do not use chemicals such as thinner or acetone, chemicals, insecticides, etc., or rough cloths that may damage the exterior of the product.

2. Product Components

2-1 Components







WEBICS Palm main body

Mount Bracket

Bottom Cover Screw(6pcs)



Mount Bracket Screw& Anchor(4pcs each)



User Manual (provided as PDF)

2-2 Sold separately (optional)



Palm Vein Register for PC







Power Supply (SMPS)

2. Product Components

2-3 Safety Precautions

The following installation tools are used to install the product and are not provided as components.



- For DC cables (12V / 3A), use products with a wire length of 2 m or less.
- Check the allowable current for the power cord and power cable and use the appropriate product. DC power cord: AWG 20 or more / DC power cable: AWG 22 or more
- To make a hole on a brick or concrete wall, use a corded power drill and a concrete drill bit together.
- When fixing the product by drilling a hole on a brick or concrete wall, use a screw anchor to fix the screw.

3. Name & Function of each part

3-1 Product Front



4. Product Size









5. Installation Environment

5-1 Installation Location

- The proper height and distance for installation and use of the product depends on the user's average height and arm length.
- The recommended installation height of the product is 130 to 140 cm above the floor.
- The recommended distance to use is 40 to 50 cm from the user's body to the product.



5-2 Cautions in use

- Install the product on a wall with a flat surface and perpendicular to the floor.
- Be sure to install the product indoors and out of direct sunlight.

6. Product installation

6-1 Bracket Installation

Install on a flat, hard wall



6-2 Power Connection



6-3 RJ45 Connection



6-4 Relay terminal connection



 \odot NO Connection







6-5 Fixing a product with the bracket



6-6 Fixing a product



7. Managing Program

7-1 Program Download

- 1. Install and run the WEBICS ADMIN program using the link provided by the customer support team.
- 2. When the WEBICS login screen appears, log in with the appropriate ID and password to display the main screen.



* ID and password are provided by the Customer Support Center.

8. Device Registration

WEBICS

Select

Select

Bashboard

Devices

Users

Settings

Settings

1. Select the Devices icon from the WEBICS ADMIN main screen.

2. Select the New button.

×	WEBICS Select				admin. Welcome to WEBICS	F
ណ	Devices 🕑 New	X Delete (Configure	e 🛛 🛛 🖉 Location	C Sync		
		NO Device Name	IP Address	Location		
		1 Device A	192.168.0.151			
8						
			HNCTS			

3. Select the Detect button.



4. Select the Registration button of the discovered device.

If multiple devices are found, select the Registration button of the device to be registered.

×	WEBICS							admin. Welcome to WEBICS	F
â	Devices	⊕ Ne	w	X Delete 🛞 C	onfigure 🔗 Location	🗇 Sync)		
▣			New			Sele	Ct Q Detect		
			NO	Device Name	MAC ADDRESS	IP	Registration		
8			1	New Device	B8:27:EB:E6:93:B9	192.168.0.152	Registration		
⋳									
٢									
							CANCEL		
					HNCTS				

5. After entering the settings of the device, select the Save button.

- Be sure to ask your computer administrator for the setting value.If the IP address does not exist or if there is a conflict, the product will not operate normally.

×	WEBICS		admin. Welcome to WEBICS
ନ	🗍 Devices 🛛 🕙 Ne	w X Delete @ Configure @ Location C Sync	
▣		congure	
		SETTING	
8		Device VER:1.00.08 Name Device B Server IP 192.168.0.35	
⋳		Network Setup	
ŵ		Address 192.168.0.152 Netmask 255.255.25 Gateway 192.168.0.1	
		(Relay)	
		Grant Access Time 3 Sec	
		Brightness 2 Step	
		System Setup	
		[Tamper Sensor] [Sound] Select	
		Disable 0.4 Sec	
		SAVE CANCEL	
		Mucra	

6. Make sure that the registered device is displayed in the Devices list.

X	WEBICS					admin, Welcome to WEBICS	P
ណ	🗍 Devices 🛛 🛞 Nev	×	Delete © Configure	Location	C Sync		
		NO	Device Name	IP Address	Location		
_			Device A	192.168.0.151			
			Device b	192.106.0.152			
8							
⋳							
\$							
				MCTS			

9. User Registration - Vein Registration

1. Select the Users icon from the WEBICS ADMIN main screen.



2. Select the Add button

×	WEBIC	s				admin. Welcome to WEBICS
ណ	(2) Use	er List 🕑 Add	Edit	× Delete		
	NO	Name	ID Number	Group	Permission	
<u> </u>		User_01		CEO		
		User_02		Sales		
8						
⋳						
0						
				H N	стя	

3. After entering the basic information of the user to be added, select the Palm Vein button.

×	WEBICS						admin. Welcome to WEBICS	F
ណ	(2) User Li	st 🛈 A	dd 🗹 Ed	it X Delete				
	NO 1 2	Name User_01 User_02	Add	User_03		Select		
© ©			ID Number Department Position Phone	3 Engineering Departme Team manager 1010-2345-6789	· @			
			Fridie Registration Date E∙mail	2021-08-02		RF Card		
						SAVE CANCEL		
					KNCTS			

4. Select the connected register in the Palm Vein pop-up window.

×	WEBICS admin, Welcome to WEBICS									
ណ	(2) Use	r List	•	Add Edit Zelete						
ē	N0 1	ι	Name User_01							
			User_02	Register Auth - Palm Vein	-					
8										
⋳				Department						
٢				Position Right Hand n Vein						
				Phone						
				Registration						
				E-mail						
				SAVE DELETE CANCEL Card						
				SAVE CANCEL						
				(<u>H</u> NCTS						

5. Register the palm vein



- Flatten the palm and place the center of the palm at a distance of 4-5 cm from the vein sensor.
- At this time, the palm and vein sensor should be parallel.
- 6. If the vein is properly registered



* Caution: The vein recognition works well when user registration is correct. For vein registration, please register 2 times per user.

9. User Registration - Card Registration

- Repeat the steps below for vein registration.
- 1. Select the Users icon from the WEBICS ADMIN main screen.
- 2. Select the Add button.
- 3. After entering the basic information, select the RF Card button.

×	NEBIC	s						admin, Welcome to WEBICS	F
â	(2) Usi	er List	•	Add 🕜 Ed	t X Delete				
	N0 1 2		Name User_01 User_02	Add Name 10 Number Department Position Phone Registration Date E-mail	User_03	© ©	Select		
					F	ICTS			

4. Check the RF Card registration pop-up.

() Use	er List 💿 A	Add E Edit X Delete	
NO	Name	Add	
1	User_01		
2	User_02		-
		Name User_03 ID Number 3 Register Auth - RF Card	
		Department Er	
		Position Te Palm Vein	
		Phone 0 RF Card ID-3	
		Registration Date 20	
		E-mail	
		RF Card	
		SAVE CANCEL	

Name	User_03	
ID Number	³ Register Auth - RF Card	dil)
Department	Er RF Card ID-1	UF .
Position	Te RF Card ID-2	Palm Vein
Phone	0 RF Card ID-3	
Registration Dat	te 20	ר י
E-mail	Device B SAVE DELETE CANCEL	
		RF Card

5. Click the device selection drop box and select the device you want to register.

7. After selecting a device, press the card number input field to change to the registration mode.

Name	User_03	
ID Number	³ Register Auth - RF Card	
Department	Er RF Card ID-1	YF -
Position	Te RF Card ID-2	Palm Vein
Phone	0 RF Card ID-3	
Registration Date	20	
E-mail	SAVE DELETE CANCEL	
		RF Card

7. When you touch the card or ring to be input on the card recognition position of the product, the card number is automatically entered.

Name	Us	er_03		
ID Number	3	Register Auth - RF Ca	rd	
Department	En	RF Card ID-1	4204432830	
Position	Те	RF Card ID-2		Palm Vein
Phone Registration Date	0	RF Card ID-3		
E-mail		Device B	SAVE DELETE CANCEL	
				RF Card

8. Click the Save button.

Name	User_03	
ID Number	³ Register Auth - RF Card	
Department	Er RF Card ID-1 4204432830	
Position	Te RF Card ID-2	Palm Vein
Phone	RF Card ID-3	
Registration Date	20	
E-mail	Device B V SAVE DELETE CANCEL	
		RF Card

9. If the card or ring is registered normally, the color of the RF Card button changes to the registered color.

Name ID Number Department	User_03 3 Engineering Departme	@	
Position	Team manager	ŵ	Palm Vein
Phone	010-2345-6789		
Registration Date	2021-08-02		
E-mail			
			RF Card



10. Managing Access Rights - Accessible Device Settings for Each User

1. Select the Access Control icon from the main screen



2. Check the registered user list and registered equipment list displayed.



- 3. Select the users whose permissions you want to change, and then specify which devices they can access.
 - * You can select multiple users. / Select the device checkbox

🗙 webics admin. W							
â	🔒 Acc	ess Control Name	Ý	۹ 🗉) SAVE		
_	NO	Name	ID Number	Group	Position		Device List
Ľ	1	User_01	1	CEO	CEO	Device B	
А		User_02		Sales	Team manager	Device A	
Ы		User_03		Engineering Departme	Team manager		
8							
⋳							

4. You can search for users in the top menu. You can select a search option from dropbox.

X webics						
۵	Acc	ess Control	Name	~	٩	P SAVE
	NO	Name	Name ID Number	umber	Group	Position
	1	User 1	Group	1	CEO	
А	2	User 2	Position	2	Sales	
8						

- 5. Click the Save button to save the settings
 - * When you click the Save button, the information stored in the server is synchronized with the device.



11. Product Use

11-1 Recognizing Veins

Fully spread your fingers and place your palm parallel on top of the vein sensor. Align the center of your palm with the center of the sensor. Then adjust the distance between the vein sensor and the palm of your hand to be about 4 to 5 cm. Wait without moving your palm while the vein sensor detects a vein.



11-2 Recognizing a card

Touch the card to the product's RFID recognition sensor (RFID image section).

12. LED indication Cases

12-1 Status In Use



Authentication completed



12-2 Registration Status







13. Product Specifications

Product Surface

Keep the product clean by cleaning it regularly. Contamination of the product surface, especially the vein sensor area, may affect product performance Gently wipe the product with a dry fabric or cloth.

- When cleaning the product, do not use alcohol, acid solutions, or strong chemical cleaners.
- The product may be damaged and the product may not function properly.
- If the product is strongly scratched or impacted, the product may not operate normally.

Firmware

Firmware can help to improve product functions and provide new functions. When a new version of the firmware is available, update information is provided on the homepage (www.ctstechno.com).

Item	Specifications
CPU	Cortex-A53 64-bit SoC 1.4GHz
RAM / Storage	1G / 16G
Encryption	AES256
Status display	LED color change
Operation mode	Palm vein, RFID
Built in RFID reader	
Event log capacity	100,000 events
Management SW	WEBICS ADMIN
Communications	Ethernet
External interface	Relay3P, RJ45
Operating temperature / Humidity	0 ~ 50 °C / 5 ~ 80 %
Power	12V DC / 3A
Dimension	120 (W) X 152 (D) X 112 (H) mm
Weight	
Housing materials	
Color	

Product Specifications

Palm recognition mode specifications

Item	Specifications
Recognition range	35~7.6cm
FAR / FRR (%)	1.0000001/0.01
Max. Capacity	500